INSTALLATION MANUAL

FOLDER DUPLO FOLDER

DF-999/DF-999A DF-990/DF-990A


Service Person Only





1. Installation Precautions

1-1. Before installation

- Check that before the installation, the power switch [A] is turned off.
- Check that the voltage and frequency of the area in which this machine is used match the specifications on the label [B] pasted on the machine.
- When removing the machine from the container, lift the bottom [C] of the machine at two people.







• A machine in the photos shown in this manual is a prototype. The colors and forms of the parts shown in the photos may be different from those of the production model.

1-2. Installation location

• Install the machine on strong solid ground which can bear the weight of the machine. The weight of the machine is as follows.

DF-999/DF-999A: 43.0 kg/94.8 lb (This unit: 41.6 kg/91.8 lb, Accessories: 1.0 kg/2.2 lb) DF-990/DF-990A: 42.0 kg/92.6 lb (This unit: 40.6 kg/89.6 lb, Accessories: 1.0 kg/2.2 lb)

• The following installation space(width x depth x height) is required.

1,112 x 512 x 554 mm/43.78 x 20.16 x 21.82 inches

- Install the machine in a flat and stable place.
- Do not install this machine near a heating equipment such as a stove.
- Install in a place which meets the following requirements.

Temperature range: 5 to 35°C, 41 to 95°F

Humidity range: 20 to 80%RH (No condensation)

No direct sunlight


Outside light does not exceed 1,500 lx

Little dusts and dirt Little vibrations

No salt

No special chemicals

No exposure to water



1-3. Power supply

• Make sure the power supply used is always within the following range.


Power supply: 100 to 240 V, 50/60 Hz

• When you power other appliances from the same wall outlet, make sure that the combined power consumption does not exceed the power supply capacity.

Rated power: 100 W

Rated current: 1.0 A to 0.5 A

2. Accessories



No.	Name	ame Qty.		Remarks
		DF-999/	DF-990/	
		DF-999A	DF-990A	
[u1]	Cross fold lever	1	1	
[u2]	Auxiliary paper ejection guide	1	1	
[u3]	Folding plate 1	1	1	
[u4]	Folding plate 2	1	1	
[u5]	Paper support guide	1	1	
[u6]	T-handle hexagonal wrench	1	1	For User (tool)
[u7]	Scale label	1	1	
[u8]	Power cord	1	1	For EU
[u9]	Power cord	1	1	For NA
[m1]	Instruction manual	1	1	
[m2]	Safety Guide A	1	1	
[m3]	DECLARATION OF CONFORMITY	1	1	For EU
[m4]	WEEE Statement	1	1	For EU
[m5]	Statement of Electromagnetic Compatibility (EMC)	1	1	For NA
[m6]	Installation manual	1	1	This manual


3. Preparation

The press release lever have been installed to avoid the deformation of the folding roller. Be sure to remove the press release lever when installing.

If the folding plate 1 is set before removing the press release lever, the folding plate 1 may become deformed or damaged. Be sure not to turn on the power before removing the press release lever.

1	Open the top cover.	

[A] Top cover......1



2	[B]	Remove the tapes that secure the press release lever. Tape	[B]
3	[C]	Remove the press release lever 1 in the direction of the arrow. Press release lever 1	
4	[D]	Remove the press release lever 2 in the direction of the arrow with the same as step 3. Press release lever 2	

4. Installation Procedures

Installation procedures of this machine, refer to the instruction manual of this machine.

5. Setting Control Panel

For the setting of the language to be displayed, refer to the service manual of this machine.